

90 WSBT Footboard Assembly Kit, 16" - 22" Deep Pronto R2 Made After 9/24/00 Only

Part Number	Description	Quantity Per Package	Quantity Per Assembly
1101545-NLA See Note(s) A	90WSBT Footboard Assembly Kit 16"-22" Deep	1	1
1099491	Footboard Assembly 90 Degree	1	1
1101083-NLA	Support w/ Pin, Legrest Tube	1	1
1003424	Screw, Socket Head Cap (1/4-20 x 1-3/4")	1	3
1026907	Locknut (1/4-20)	1	3
7930333	Locknut (1/4-20)	25	5
20105X000-NLA	Washer, Flat (1/4 x 5/8 x 1/16")	1	6
1024793-NLA	Screw, Hex Head Cap (1/4-20 x 1-3/4")	1	4
1028600-NLA	Screw, Hex Head Cap (5/16-24 x 3")	1	2
7930330-NLA	Locknut (5/16-24)	25	2
1100861-NLA	Instruction Sheet, Footboard Adjustment	1	1
1100863-NLA	Instruction Sheet, Footboard Mounting	1	1
1101410-NLA See Note(s) B	Packaging, Footboard Assembly, 90 Degree	3	1
1086767-NLA	Carton, Shipper	1	1
1021148-NLA	Bag, Poly Zip Lip (8-3/4" L x 6" W)	1	1
1021149-NLA	Bag, Poly Zip Lip (13" L x 9" W)	1	1
47568X003-NLA	Bag, Poly (30" L x 24" W)	1	1
1096519-NLA	Tube, Support w/ Plug Button	1	2
NOTE: A - Consists of all components listed below B - Consists of 3 Cable Ties 11 1/2 Long			