

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

Legrest tube
reference only.

90 Degree One Piece Footboard Assembly

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1	A	1094014-NLA	NLA - Footboard Assembly, 90 Degree One Piece (14" W - 16" W)	1	1
1	A	1094015-NLA	NLA - Footboard Assembly, 90 Degree One Piece (17" W - 24" W)	1	1
2		1091547-NLA	NLA - Cam, Mounting Bracket, Upper	1	2
3		1025705-NLA	NLA - Screw, Hex Head (5/16-24 x 3-1/4")	1	1
4		1089296-NLA	NLA - Pin, Detent (5/16 x 3")	1	1
5		7930330-NLA	NLA - Locknut (5/16-24)	1	2
6		1090552-NLA	NLA - Bracket, Upper Mounting, Black	1	1
7		1026032	Washer, Nylon (11/32 x 11/16 x 1/16")	1	2
8		1089300-NLA	NLA - Tube, Legrest	1	1
9		1074210-NLA	NLA - Washer, Nylon (23/64 x 3/4 x 5/32")	1	2
10		1028835-NLA	NLA - Cap, Hub, Black	1	2
11		1028491-NLA	NLA - Washer, Caplugs (11/32" I.D. x 1" O.D.)	1	2
12		1090551-NLA	NLA - Bracket, Footboard Pivot, Black	1	1
13		1058517	Clamp, Footplate	1	2
14		1027097	Plug Button, Black (3/4")	1	2
15		1029545	Screw, Socket Flat Head (1/4-20 x 3/4")	1	4
16		1082686	Nut, Barrel, Hex Head (1/4-20 x 11/16")	1	4
17		1090553-NLA	NLA - Footboard, One Piece 90° (14" W thru 16" W)	1	1
17		1090554-NLA	NLA - Footboard, One Piece 90° (17" W Thru 24" W)	1	1
18	B	1092914-NLA	NLA - Hardware, Mounting, 90 Degree One Piece Footboard	1	1
19		1039860	Screw, Hex Head w/ Patch (5/16-18 x 3/4")	1	3
20		1025704	Washer, Flat (5/16 x 5/8 x 1/16")	1	3
21	C	1095356-NLA	NLA - Kit, Footboard, 90 Degree One Piece (14 - 16" W)	1	1
21	C	1095357-NLA	NLA - Kit, Footboard, 90 Degree One Piece (17 - 24" W)	1	1
	D,E	1094558-NLA	NLA - Instruction Sheet, 90° One Piece Footboard Assembly	1	1

NOTE: A - Includes Items 2-17.
 B - Includes Items 19 and 20.
 C - Includes Items 1, 18 and Instruction Sheet.
 D - Not Shown
 E - Item is no longer available from the Invacare Service Parts Department. Refer to the Invacare Website under "Product Literature Search". Enter the part number in the "Keywords" field and download a free PDF version copy.

NOTE: When converting to a 90° one piece footboard assembly that was not originally ordered with a chair, a notched front shroud to give legrest tube clearance is required. Notched front shrouds became standard on all chairs after 2/17/00. See shroud color conversion kits for chairs manufactured before 2/18/00. Seat pan attaching hardware (part # 1094381) must be ordered as well.