


# Battery Harness, Cables and Charger



## Battery Harness, Cables and Charger

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1		1099754-NLA	NLA - Charging Cable, On Board with Hardware (Lynx SX3/ LX3/ LX3 Plus and Panther MX4) Includes: (1) Charging Cable, (2) Screw, Phillips Pan Head (M3 x 0.5 x 16) 2 ea. Washer (3.2 x 10 x 0.8) 2 ea. Locknut (M3 x 0.5 x 6) 2 ea. Cable Tie 1 ea. Tube, PVC (19 x 20 x 260L)	1	1
2	A	1099753-NLA	NLA - Charger, Battery, On-Board	1	1
2	B	1053161-NLA	NLA - Charger, Battery, 8 Amp, 115vac, Off Board Dual Mode Round Plug, Lester	1	1
3		1099744-NLA	NLA - Strap, Fastening - On-Board Charger	1	1
4		1088745-NLA	NLA - Cord, Charger, AC	1	1
5		1088742-NLA	NLA - Strap, Carrying, Battery	1	2
6		1099760-NLA	NLA - Strap, Fastening - Battery	1	1
7		1099752-NLA	NLA - Harness, Power Connector, Circuit Breaker Cables and Hardware Includes: 1 ea. Harness Power Connector 2 ea. Cover, Battery Terminal (Red) 2 ea. Cover, Battery Terminal (Black) 1 ea. Cable, Circuit Breaker (Red) 1 ea. Cable, Circuit Breaker (Black) 1 ea. Tube, Snake (10 x 110L) 1 ea. Tube, Snake (10 x 95L) 4 ea. Screw, Hex Head Cap (M6 x 1.0 x 12) 4 ea. Hexnut (M6 x 1.0 x 10) 4 ea. Cable Tie	1	1
8		1088748-NLA	NLA - Circuit Breaker (30 AMP) - Lynx SX3P/ SX3/ LX3/ LX3 Plus, Panther LX4 and Zoom-3	1	1
9		1099772-NLA	NLA - Charger Cable Cover Assembly Includes: 1 ea. Cover, Charger Cable 1 ea. Screw, Phillips Pan Head (M4 x 0.7 x 12) 1 ea. Washer (M4 x 9 x 1) 1 ea. Locknut (M4 x 0.7 x 7)	1	1
NOTE: A - (On-Board) Battery Charger #1099753 is no longer available. Use the (Off Board) Charger part #1053161 as a replacement. B - Use Battery Charger part number 1123249 as a replacement.					