



Seat/Chest Positioning Straps




Auto Style Push Button Buckle Positioning Strap



Airline Style Buckle Positioning Strap



Hook and Loop Style Buckle Positioning Strap



Seat/Chest Positioning Straps

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1		See Chart	#1 Airline Style Positioning Strap	1	1
1		See Chart	#1 Auto Style Push Button Positioning Strap	1	1
1		See Chart	#1 Hook and Loop Style Positioning Strap	1	1
2		1037610	Screw, Hex Head (1/4-20 x 1-5/8")	1	2
3		1025736	Locknut (1/4-20)	1	2

All chest positioning straps can only be used on chairs with A.S.B.A. seats.

#1 Auto Style Push Button Positioning Strap

Chair Width	Part Number	Seat/Chest Positioning Strap w/ Auto Style Buckle Length (Eyelet to Eyelet)
16" - 19" Wide	1004310	48" L
20" - 22" Wide	1034625	61" L
23" - 24" Wide	1124380	94" L

#1 Airline Style Positioning Strap

Chair Width	Part Number	Seat/Chest Positioning Strap w/ Airline Style Buckle Length (Eyelet to Eyelet)
16" - 19" Wide	TAGTS1034751-NLA	46" L
20" - 22" Wide	1034752-NLA See Note(s) A	61" L
23" - 24" Wide	1124381	94" L

NOTE: A - 1034752 Airline Buckle Style is No Longer Available. Use Auto Style part number 1034625 as a replacement.

#1 Hook and Loop Style Positioning Strap

Chair Width	Part Number	Seat/Chest Positioning Strap w/ Hook and Loop Style Buckle Length (Eyelet to Eyelet)
18" - 22" Wide	1034745 See Note(s) A	61" L

NOTE: A - Hook and Loop Style Positioning Straps for power chairs used for chest positioning only.