

# Front Riggings Reference Chart

## For 70MFX and 90 SWING

**NOTE: Footplates do not include heel loops. See footrest and legrest accessories.**

AT5543 = Adjustable angle footplates without pivot/slide tubes.
AT5043 = Flip up footplates without pivot/slide tubes.

### Support Assemblies

**Footplate Assemblies are interchangeable with the support assemblies listed.**

Rigging Type	70MFX
Right	8881047481 <small>See Note(s) A</small>
Left	8881047480 <small>See Note(s) A</small>

NOTE: A - Specify frame color when ordering, see page titled "Frame Finishes and Touch-Up Paints".

### Support Assemblies

**Footplate Assemblies are interchangeable with the support assemblies listed.**

Rigging Type	90 SWING
Right	8881062596 <small>See Note(s) A</small>
Left	8881062597 <small>See Note(s) A</small>

NOTE: A - Specify frame color when ordering, see page titled "Frame Finishes and Touchup Paints".

### Footplate Assemblies

Footplate Type	AT5043 12-16" W	AT5543 12-13" W	AT5543 14-15" W	AT5543 17-24" W
Right	1029434-NLA	1060436-NLA	1060438	1062570
Left	1029435-NLA	1060437	1060439	1062571