


# SD Memory Card and Reader (USB Ready) (1813SD)



Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1	A	1145396	Kit, SD Card Professional (USB Ready) (1813SD)	1	1
2			NLA - Bag, Poly Zip-Lip (13" L x 9" W)	1	1
3			Card, SD Professional	1	1
4			Holder, Card Memory	1	1
5			NLA - Instruction Sheet, Memory Card	1	1
6			NLA - Drive, Flash Memory Removable	1	1
5		1143175-NLA	NLA - Instruction Sheet, Memory Card	1	1
7		1144515	Card, SD Basic	1	1
8		1144516	Card, SD Professional	1	1

NOTE: A - Includes items 2-6.