


Seat Base Assembly



Seat Base Assembly

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1		460009-2	Base, Seat (15" W x 15" D)	--	1
1		460009-3	Base, Seat (15" W x 16" D)	--	1
1		460009-4	Base, Seat (15" W x 17" D)	--	1
1		460009-5	Base, Seat (15" W x 18" D)	--	1
1		460009-6	Base, Seat (15" W x 19" D)	--	1
1		460009-9	Base, Seat (16" W x 15" D)	--	1
1		460009-10	Base, Seat (16" W x 16" D)	--	1
1		460009-11	Base, Seat (16" W x 15" D)	--	1
1		460009-12	Base, Seat (16" W x 18" D)	--	1
1		460009-13	Base, Seat (16" W x 19" D)	--	1
1		460009-16	Base, Seat (17" W x 15" D)	--	1
1		460009-17	Base, Seat (17" W x 16" D)	--	1
1		460009-18	Base, Seat (17" W x 17" D)	--	1
1		460009-19	Base, Seat (17" W x 18" D)	--	1
1		460009-20	Base, Seat (17" W x 19" D)	--	1
1		460009-23	Base, Seat (18" W x 15" D)	--	1
1		460009-24	Base, Seat (18" W x 16" D)	--	1
1		460009-25	Base, Seat (18" W x 17" D)	--	1
1		460009-26	Base, Seat (18" W x 18" D)	--	1
1		460009-27	Base, Seat (18" W x 19" D)	--	1
1		460009-30	Base, Seat (19" W x 15" D)	--	1
1		460009-31	Base, Seat (19" W x 16" D)	--	1
1		460009-32	Base, Seat (19" W x 17" D)	--	1
1		460009-33	Base, Seat (19" W x 18" D)	--	1
1		460009-34	Base, Seat (19" W x 19" D)	--	1
1		460009-37	Base, Seat (20" W x 15" D)	--	1
1		460009-38	Base, Seat (20" W x 16" D)	--	1
1		460009-39	Base, Seat (20" W x 17" D)	--	1
1		460009-40	Base, Seat (20" W x 18" D)	--	1
1		460009-41	Base, Seat (20" W x 19" D)	--	1
2		1001762	Screw, Socket Button Head (1/4-20 x 1-3/4")	--	4
3		1025736	Locknut (1/4-20)	--	4
4		1025704	Washer, Flat (5/16 x 5/8 x 1/16")	--	4