



MCCX Switch Option Interface

Before 4/1/96



MCCX Switch Option Interface

Before 4/1/96

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1		1036493-NLA	NLA - Switch Option with Instructions	1	1
2		1025516-NLA	NLA - Knob, Speed Control	1	1
3		1028083	Decal, Speed Pot	1	1
4		1010049-NLA	NLA - Boot, Switch	1	1
4		1010048-NLA	NLA - Switch, Push Button SPST	1	1
5	C	1010042-NLA	NLA - Switch, Toggle SPDT	1	1
6		1011719-NLA	NLA - Light, Tri-Colored LED with Wires	1	1
6	A	1011699-NLA	NLA - Light, Tri-Colored LED without wires	1	1
7		1028529	Screw, Phillips Pan Head (#8-32 x 3/8")	1	8
8		1020818	Switch, Red Flex Ribbon (Tape) Reset	1	1
8	B	1123276	Kit, Switch, Black Egg Reset w/ Hook/Loop Adhesive Back Fastener & Attaching Screws (EGSBLK)	1	1
NOTE: A - Order 1011719 with wires B - Not Shown. After 5/23/04 the Egg Reset Switch became available as a service part and can be used as a direct replacement for the tape reset switch part # 1020818. C - Black Switch is no longer available. The Chrome Switch part number 1010042 serves as a direct replacement					