


# Casters (After 6/29/11)

## Standard Caster Components

(Some Components may not be available as Stand Alone Service Parts)



## Casters

Caster Option	Wheel Size	Tire Type	Caster Assembly	Rear Wheel Option	Seat to Floor Dimension
AT900	4 x 1"	Urethane	1032190-NLA	12COM 22COM	16 - 17" 16-1/2 - 17"
41DC	4 x 1"	Urethane	1164317-NLA	12COM 22COM	15-1/2, 16, 16-1/2, 17, 17-1/2"
51DC	5 x 1"	Urethane	1169260	12COM 20COM 22COM 24COM	16 - 17-1/2" 17-1/2" 16-1/2" - 17-1/2" 17-1/2"
61DC	6 x 1"	Urethane	1164314	12COM 20COM 22COM 24COM	17, 17-1/2" 17-1/2" - 18-1/2" 17 - 18" 17-1/2 - 18-1/2"
615DC	6 x 1-1/2"	Urethane	1164313	12COM 20COM 22COM 24COM	17, 17-1/2" 17-1/2" - 18-1/2" 17 - 18" 17-1/2 - 18-1/2"
1259	6 x 2"	Semi Pneumatic Urethane	1115179	12COM 20COM 22COM 24COM	17-1/2" 17-1/2", 19" 17-1/2" 17-1/2", 19"
81DC	8 x 1"	Urethane	1164315	20COM 24COM	18-1/2"
815DC	8 x 1-1/2"	Urethane	1164316	20COM 24COM	18-1/2"

NOTE: Caster Wheel Assembly includes the following items: Tire, Wheel, Bearings (2), and Spacer.