


Casters & Hardware (After 6/29/11)



Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1		1026908	Screw, Hex Head (5/16-24 x 2-1/2")	1	1
2		1025730	Locknut (5/16-24)	1	1
3		1026160	Spacer (5/16 x 7/16 x 3/8")	1	2
4		1028539	Spacer (15/32 x 5/16 x 3/16)	1	2
5		1025704	Washer, Flat (5/16 x 5/8 x 1/16")	1	2
6		See Chart	Caster Wheels (After 6/29/11)	1	1

Caster Wheels

Wheel Style	Wheel Size	Tire Type	Wheel Assembly See Note(s) A	Bearing Spacer	Bearing	Tire	Tube/Insert
AT900	3"	Urethane	1032190-NLA	1026172	40117X026	N/A	N/A
41DC	4"	Urethane	1164317-NLA	N/A	N/A	N/A	N/A
51DC	5 x 1"	Urethane	1169260	N/A	N/A	N/A	N/A
61DC	6 x 1"	Urethane	1164314	N/A	N/A	N/A	N/A
615DC	6 x 1-1/2"	Urethane	1164313	N/A	N/A	N/A	N/A

NOTE: A - Wheel includes Tire, Bearings and/or Spacer.