









Jet Assembly

WHEN REPLACING THE JET FLANGE,
THE TORQUE SPECIFICATION IS 9 - 11 FT./LBS.



Jet Assembly

WHEN REPLACING THE JET FLANGE,
THE TORQUE SPECIFICATION IS 9 - 11 FT./LBS.

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1	A	1094363	Jet Assembly, White	1	1
2		PAR7182E	Jet Housing	1	1
3		PAR7188	Gasket	1	1
4		IHPAR7185F-W S	Nut, White Flange	1	1
5		IHPAR7185EWP P	Push and Pull Jet and Gasket	1	1
6		IHPAR7189	Gasket, Replacement Jet	1	1
7		IHPAR7186	Wrench, Jet Spanner	1	1
8		IHPAR7187	Wrench, Flange Spanner (For Jet Flange and Inlet Suction Guard Heads)	1	1

NOTE: A - Includes items 1 - 5.