






# Accessories - Remote (Joystick) Tops



SHEP\_223B



## Accessories - Remote (Joystick) Tops

| Item Number | Note | Part Number  | Description  | Quantity Per |          |
|-------------|------|--------------|--|--------------|----------|
|             |      |              |  | Package      | Assembly |
| 1           |      | 60102547     | Kit, Handle, Joystick, 3" U Shaped                                 | 1            | 1        |
| 1           |      | 60102549     | Kit, Handle, Joystick, 4" U Shaped                                 | 1            | 1        |
| 2           |      | 60102588     | Kit, Handle, Joystick, Dome Rubber                                 | 1            | 1        |
| 3           |      | 60106526     | Kit, Handle, Joystick, Grooved Mushroom                            | 1            | 1        |
| 4           |      | 60102524     | Kit, Chin Cup Assembly - 1826                                      | 1            | 1        |
| 5           |      | 60102590-NLA | NLA - Kit, Handle, Joystick, Ball Knob                             | 1            | 1        |
| 6           |      | 60102589-NLA | NLA - Kit, Handle, Joystick, Mushroom Head                         | 1            | 1        |
| 7           |      | 60102587-NLA | NLA - Kit, Handle, Joystick, Blue Aluminum Top                     | 1            | 1        |
|             | A    | 60102586     | Kit, Extension, Joystick, "T" Style (1560)<br>(4" W x 5-1/2" L)    | 1            | 1        |
|             | A    | 60102585     | Kit, Extension, Joystick, Straight Style (1561)<br>(1/2" W x 5" L) | 1            | 1        |

NOTE: A - Not Shown