




# Accessories - Acrylic Trays



## Accessories - Acrylic Trays

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1		See Chart	#1 Acrylic Tray - Standard Trays - Before 10/17/18	1	1
1		See Chart	#1 Acrylic Tray - Standard Trays - After 10/16/18	1	1
2		See Chart	#2 Acrylic Tray - Swing Out	1	1
3		L10024	Knob, Tray	1	1

### #1 Acrylic Tray - Standard Trays - Before 10/17/18

Chair Width	Tray (ACTRY) Part Number
12" Wide	1492757
13" Wide	1492758
14" Wide	1492759
15" Wide	1450921
16" Wide	1450922
17" Wide	1450923
18" Wide	1450924
19" Wide	1450925
20" Wide	1450926

Item includes Tray and Mat.

### #1 Acrylic Tray - Standard Trays - After 10/16/18

Chair Width	Tray (ACTRY) Part Number
15-16" Wide	1601454
17-18" Wide	1601458
19-20" Wide	1601459

Item includes Tray and Mat.

# Accessories - Acrylic Trays

## #2 Acrylic Tray - Swing Out

Models	8 - 9" Wide Chair	10 - 11" Wide Chair	12 - 13" Wide Chair	14 - 15" Wide Chair
ACTRSA ACTLSA	1513253	1513254	1513255	1513256
Item includes Tray, Knob, Support and Screws				