



Dual Toggle Switch (2SW) & Monoport "Y" Phono Cable (MPY)



Egg Switch (EGSBLK)

SHEP_343A

Dual Toggle Switch (2SW) & Monoport "Y" Phono Cable (MPY)

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1	A	1091496	Kit, Joystick Tube Toggle Switch Mounting Hardware	1	1
2			NLA - Half Clamp, Threaded Holes	1	1
3			Half Clamp, Non-Threaded Holes	1	1
4			Screw, Hex Head w/ Patch (1/4-20 x 1/2")	1	2
5			NLA - Bracket, Toggle Switch Mounting, Black	1	1
6			NLA - Screw, Hex Head (1/4-20 x 1-1/8")	1	2
7		60102516	Kit, Switch, Dual Function Toggle (2SW)	1	1
8		1140027	Cable, Monoport "Y" Phono (MPY)	1	1
9		60102517	Kit, Switch, Black Egg Reset w/ Hook/Loop Adhesive Back Fastener & Attaching Screws (EGSBLK)	1	1
NOTE: A - Includes items 2-6					