
Tilt Angle Sensor Assembly w/ Hardware



Tilt Angle Sensor Assembly w/ Hardware

| Item | | | | Quantity Per | |
|--------|------|-------------|--|--------------|----------|
| Number | Note | Part Number | Description | Package | Assembly |
| 1 | Α | 60125835 | Kit, Tilt Angle Sensor w/ Hardware | 1 | 1 |
| 2 | | | Tilt Angle Sensor w/ Connector Assembly | 1 | 1 1 |
| 3 | | | Screw, Socket Head Cap (M4 x 0.7 x 10mm) | 1 | 1 1 |
| | | | Sheet, Insert Parts Service | 1 | 1 1 |
| 4 | В | 60124877 | Kit, Tilt Angle Sensor Bracket w/ Hardware, ULMTR | 1 | 1 |
| 5 | | | Screw, Socket Head Cap w/ Patch (M8 x 1.25 x 16mm) | 1 | 1 |
| 6 | | | Nut, Tee (M8 x 1.25mm) 2 Hole | 1 | 1 |
| 7 | | | Plate, Tilt Sensor Mounting | 1 | 1 |
| | | | Sheet, Insert Parts Service | 1 | 1 |
| 8 | С | 60124958 | Kit, Tilt Angle Sensor Bracket, ULMT | 1 | 1 1 |
| | | | Bracket, Sensor Angle Non-Recline | 1 | 1 1 |
| | | | Sheet, Insert Parts Service | 1 | 1 1 |

NOTE: A - Includes items 2 and 3
B - Used for ULMTR. Includes items 5-7
C - Used for Non-Recline Rehab Seating System.