


Seat Frame Attaching Hardware

Basic Recline 4XP



Seat Frame Attaching Hardware

Basic Recline 4XP

Item Number	Note	Part Number	Description	Quantity Per	
				Package	Assembly
1		0140506-NLA	NLA - Screw, Socket Head w/ Thread Lock (5/16-18 x 1")	1	4
2		0054806-NLA	NLA - Washer, Flat (11/32 x 11/16 x 1/16")	1	4
3		0131406	Screw, Hex Head (5/16-18 x 1-3/4")	1	4
4		0139900	Washer, Nylon (1/2 x 3/4 x 3/32")	1	8
5		0280700-NLA	NLA - Bushing (5/16 x 1/2 x 7/8")	1	4
6		0054906	Locknut, High Profile (5/16-18)	1	4
7		0055406-NLA	NLA - Screw, Machine, Button Head, Socket (5/16-18 x 1")	1	2
8		1072692-NLA	NLA - Lockwasher, Split (5/16")	1	2
9		0115724	Link, Tilt, Black - Lower	1	2
10		0215300	Bracket, Seat Support, Black	1	2
11		0139606-NLA	NLA - Screw, Hex Head (5/16-18 x 1")	1	2
12		1077373	Hardware Assembly, Seat Attaching - 4XP	1	1