




# Back Canes




**10 Degree Bend Back Cane**  
**(A1418 / AT20)**




**Straight Back Cane**  
**(A1216 / S1418)**



**Fixed Height Back Cane**  
**(FBH12 - FBH20)**



**Sportster Back Cane**  
**(1014)**



**Adjustable Angle Back Cane**  
**(AAB1216 / AAB1720)**

## Back Canes

| Item Number                                                                                                                                                                                 | Note | Part Number | Description                                       | Quantity Per |          |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------|-------------|---------------------------------------------------|--------------|----------|
|                                                                                                                                                                                             |      |             |                                                   | Package      | Assembly |
| 1                                                                                                                                                                                           | A    | See Chart   | #1 Back Canes                                     | 1            | 1        |
| 2                                                                                                                                                                                           |      | 1003545     | Screw, Socket Head (1/4-20 x 1-1/4")              | 1            | 1        |
| 3                                                                                                                                                                                           |      | 1107516-NLA | NLA - Tube, Rear Upright, Black                   | 1            | 1        |
| 4                                                                                                                                                                                           |      | 1011511     | Spring, Compression (5/8 x 1 x 3/64")             | 1            | 1        |
| 5                                                                                                                                                                                           |      | 1058545     | Lever, Actuator                                   | 1            | 1        |
| 6                                                                                                                                                                                           |      | 1059271     | Tip, Plastic, Black                               | 1            | 1        |
| 7                                                                                                                                                                                           |      | 1025195     | Locknut (1/4-20)                                  | 1            | 1        |
| 8                                                                                                                                                                                           |      | 1027097     | Plug Button, Black (3/4")                         | 1            | 1        |
| 9                                                                                                                                                                                           | B    | 1006229     | Grip, Foam (8")                                   | 1            | 1        |
| 10                                                                                                                                                                                          | C    | 1061484     | Grip, Handle, Foam, Black (5")                    | 1            | 1        |
| 11                                                                                                                                                                                          |      | 1056328     | Plug Button, Black (1")                           | 1            | 1        |
| 12                                                                                                                                                                                          |      | 1028429-NLA | NLA - Grip, Foam (6")                             | 1            | 1        |
| 13                                                                                                                                                                                          |      | 1025765     | Locknut (1/4-28)                                  | 1            | 4        |
| 14                                                                                                                                                                                          |      | 1055309     | Screw, Socket Button Head (1/4-28 x 1-1/4")       | 1            | 2        |
| 15                                                                                                                                                                                          | D    | 1113508     | Cane, Back, Black (12 - 16" H)                    | 1            | 1        |
| 15                                                                                                                                                                                          | E    | 1113509     | Cane, Back, Black (17 - 20" H)                    | 1            | 1        |
| 16                                                                                                                                                                                          |      | 1059284-NLA | NLA - Screw, Socket Button Head (1/4-28 x 1-1/4") | 1            | 2        |
| 17                                                                                                                                                                                          |      | 1025736     | Locknut (1/4-20)                                  | 1            | 1        |
| 18                                                                                                                                                                                          |      | 1114702-NLA | NLA - Insert, Back Cane, Black                    | 1            | 2        |
| 19                                                                                                                                                                                          | D,F  | 1113510     | Adjustable Angle Back Cane Assembly               | 1            | 1        |
| 19                                                                                                                                                                                          | E,F  | 1113511     | Adjustable Angle Back Cane Assembly               | 1            | 1        |
| NOTE: A - Sportster Cane Only<br>B - Used on Straight and 10 Degree Back Canes<br>C - Used on Fixed Height Back Canes<br>D - 12-16" High<br>E - 17-20" High<br>F - Includes items 1,2,12-18 |      |             |                                                   |              |          |

## #1 Back Canes

| Back Cane Style | Description                                       | Part Number                  |
|-----------------|---------------------------------------------------|------------------------------|
| A1418           | 10 Degree Bend Cane<br>w/ Push Handle 14-18" High | 1094586<br>See Note(s) A     |
| AT20            | 10 Degree Bend Cane<br>w/ Push Handle 20" High    | 1094587<br>See Note(s) A     |
| A1216           | Straight Cane w/ Push Handle 12-16"<br>High       | 1094925<br>See Note(s) A     |
| S1418           | Straight Cane w/ Push Handle 14-18"<br>High       | 1094926<br>See Note(s) A     |
| FBH12           | Straight Fixed Back Cane<br>12" High              | 1107526-NLA<br>See Note(s) B |
| FBH14           | Straight Fixed Back Cane<br>14" High              | 1107527-NLA<br>See Note(s) B |
| FBH16           | Straight Fixed Back Cane<br>16" High              | 1059263-NLA<br>See Note(s) B |
| FBH18           | Straight Fixed Back Cane<br>18" High              | 1059265<br>See Note(s) B     |

# Back Canes

## #1 Back Canes

| Back Cane Style                                                                                                                                                                                             | Description                                        | Part Number              |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------|--------------------------|
| FBH20                                                                                                                                                                                                       | Straight Fixed Back Cane<br>20" High               | 1059249<br>See Note(s) B |
| 1014                                                                                                                                                                                                        | Sportster Cane 10-14" High                         | 1094588<br>See Note(s) C |
| AAB1216 / AAB1720                                                                                                                                                                                           | Adjustable Angle Back Cane<br>12-16" & 17-20" High | 1113533<br>See Note(s) D |
| NOTE: A - Includes Back Cane and items 2,9, & 17.<br>B - Items 10 and 11 not included, must be ordered separately.<br>C - Includes Back Cane and items 2,7, & 8.<br>D - Includes Back Cane and items 12-14. |                                                    |                          |